

SOPRANO AND ALTO RECORDER FOR THE DISABLED

This **soprano** recorder so designed that players who are handicapped because of finger disabilities can play as well, or almost as well, as people with normal dexterity. A person with any six usable fingers can play an entire chromatic scale from c'' to a'''. If seven fingers are available in any combination, the range is extended by three semitones.

Alto recorder is designed to be used by players who have finger disabilities in one hand. By positioning of the body joints and tone holes the recorder can be used with either a left or right hand disability.

Sopranino

Symphony

Garklein

Symphony



204AF

309AF-E



501S(E)

506B(G)
507B(E)

Alto

Robin *Bel Canto*



209B(E)

309A(E)

Soprano

Elite

Elite

Robin

Bel Canto

Symphony

Haka

Haka (Palisander Coating)



102N(G)

202A(G)

302A(G)

204A(G)

104A(G)

502B(G)

702B(G)

702BW(G)

103N(E)

203A(E)

303A(E)

205A(E)

105A(E)

503B(E)

703B(E)

703BW(E)

(1-pc.)

(302A ivory color)